





2-1/4" (door thickness) 1-3/4" 1-3/8"

Installation Template for E308-35 Mortise Lock(85mm C~C) 240

Line for Strike

Edge bore

Face bore

E308-35

209

mortise 2-1/8" deep

backset 25mm

Through bolting holes for Lever rosette. dia 3/8" drill only if needed

152

Lever hole dia 7/8"

Fold on dotted line and attach to the door at desire height. Mark the position of necessary lines for Face and Edge bore. Please read this template and the Trim set installation menu carefully before drilling and mortising the door.

C to C 85mm

1.5" (38.1mm)

Cylinder hole dia 7/8" drill twice

68

59

50

Holes x 2 for cylinder rosette. Drill only if needed

31

Line for Strike

dia 3/4"

Check the drawing measurements if reprint

Face bore/ Entrance function illustrated.

